


OPERATION PARAMETERS DIAGRAM



- NOTES:
- The last 3 characters depend on the type of alarm configured
 - Absolute setpoint limits are set in configuration.
- Shaded boxes are only visible when FULL access level is chosen
 - No need to change
 - Cannot be changed